





Grown...to meet challenges

# INSTRUCTION MANUAL

## COAT-ENDURE

Admittance Level Limit Switch

Version 3.1



## SAPCON INSTRUMENTS PVT. LTD.

30+ Years in Process Control Instrumentation

An ISO 22000 company

[www.sapconinstruments.com](http://www.sapconinstruments.com)

# Contents

Revision History . . . . .	7
1 Introduction . . . . .	8
2 Operating Principle . . . . .	8
3 Features . . . . .	8
4 Applications . . . . .	8
5 Electrical Specifications . . . . .	9
6 Mechanical Specifications . . . . .	9
7 Application Specifications . . . . .	10
8 Installation Guidelines . . . . .	10
9 Electrical Connections . . . . .	10
10 Calibration . . . . .	11
10.1 Calibration for Non-conductive Material . . . . .	11
10.2 Calibration for Conductive Material . . . . .	11
11 Cover Delay . . . . .	12
12 Uncover Delay . . . . .	12
13 Sensitivity . . . . .	13
14 Failsafe . . . . .	14
15 Display Indications . . . . .	14
15.1 STATUS LED . . . . .	14
15.2 LED Bar Display . . . . .	14
16 Factory Reset . . . . .	14
17 Output Options . . . . .	15
18 For AS-Interface Module . . . . .	15
18.1 AS-Interface Topology . . . . .	15
18.2 Electrical Specifications . . . . .	15
18.3 AS-i Configuration . . . . .	15
18.4 Electrical Connections . . . . .	15
18.5 Setting Up AS-Interface . . . . .	16
18.6 Installation . . . . .	16
19 Error Indication . . . . .	16
20 For Namur Module . . . . .	17
20.1 Electrical Specifications . . . . .	17
20.2 Mechanical Specifications . . . . .	17
21 Namur Isolation Barrier Specs . . . . .	17
22 Installation Guidelines . . . . .	18
22.1 Electrical Connections . . . . .	18
22.2 Calibration . . . . .	18
22.3 Normal Calibration . . . . .	19

---

22.3.1 Calibration for Non-conductive Material . . . . .	19
22.3.2 Calibration for Conductive Material . . . . .	19
22.4 Remote Calibration . . . . .	20
22.4.1 Calibration for Non-conductive Material . . . . .	20
22.4.2 Calibration for Conductive Material . . . . .	21
23 Output Current Configuration . . . . .	21
23.1 Low Current Configuration . . . . .	21
23.2 High Current Configuration . . . . .	22
24 Sensitivity . . . . .	22
25 Failsafe . . . . .	23
26 Factory Reset . . . . .	23
27 Certification . . . . .	24
28 Maintenance . . . . .	24
28.1 Customer Support . . . . .	24
29 AS-Interface Order Code . . . . .	25
30 Product Selection Order Code . . . . .	27
31 AS-Interface Order Code . . . . .	29

# List of Figures

1	Coat-Endure	8
2	Description of Parts	8
3	Proper Mounting Arrangement	10
4	Coat-Endure with Baffle	10
5	Cable Gland Arrangement	10
6	Electrical Connections	10
7	Calibration for Non-conductive Material	11
8	DIP Switch	11
9	Calibration Switch Position	11
10	Setting Calibration	11
11	Saving Calibration	11
12	Calibration for Conductive Material	11
13	High Calibration Switch Position	12
14	Setting Calibration	12
15	Saving Calibration	12
16	DIP Switch	12
17	Cover Switch Position	12
18	Setting Cover Delay	12
19	Saving Cover Delay	12
20	Uncover Switch Position	13
21	Setting Uncover Delay	13
22	Saving Uncover Delay	13
23	Sensitivity Bar Display	13
24	Setting Sensitivity	13
25	Setting Sensitivity	13
26	Failsafe High	14
27	Failsafe Low	14
28	LED Indication on Top Cover	14
29	Demonstration of LED Bar Display	14
30	Switch Position	15
31	Setting Default Value	15
32	Saving Default Value	15
33	Single Point Switching without Material	15
34	AS-Interface	15
35	Electrical Connection	16
36	Connection of Coat-Endure via AS-Interface	16
37	Output of AS-Interface	16
38	Grounding Length in an Application Tank	18

39	Calibration at safe zone . . . . .	18
40	Coat-Endure with Baffle . . . . .	18
41	Cable Gland Arrangement . . . . .	18
42	Electrical Connection during installation . . . . .	18
43	Metallic Test Tank . . . . .	19
44	Calibration without Material . . . . .	19
45	DIP Switch . . . . .	19
46	Calibration Switch Position . . . . .	19
47	Setting Calibration . . . . .	19
48	Saving Calibration . . . . .	19
49	Calibration for Conductive Material . . . . .	20
50	High Calibration Switch Position . . . . .	20
51	Setting Calibration . . . . .	20
52	Saving Calibration . . . . .	20
53	Remote Air Calibration Setup . . . . .	20
54	Power ON Condition . . . . .	20
55	Remote High Calibration Setup . . . . .	21
56	High Calibration Power ON Condition . . . . .	21
57	Switch Position Low Current Configuration . . . . .	21
58	Setting of Low Current Configuration . . . . .	21
59	Saving of Low Current Configuration . . . . .	22
60	Sensitivity Setting . . . . .	22
61	Sensitivity Switch Position . . . . .	22
62	Setting Sensitivity Position . . . . .	22
63	Saving Sensitivity . . . . .	23
64	Failsafe High . . . . .	23
65	Failsafe Low . . . . .	23
66	Switch Position . . . . .	23
67	Setting Default Value . . . . .	23
68	Saving Default Value . . . . .	23

# List of Tables

1	Electrical Specifications . . . . .	9
2	Mechanical Specifications . . . . .	9
3	Application Specifications . . . . .	10
4	Sensitivity . . . . .	14
5	Electrical Specifications . . . . .	15
6	AS-i Configuration . . . . .	15
7	Error Indication . . . . .	16
8	Electrical Specifications . . . . .	17
9	Mechanical Specifications . . . . .	17
10	Namur Isolation Barrier Specifications . . . . .	17
11	Operating Conditions of Output Current . . . . .	21
12	Switching Sensitivity . . . . .	22
13	Certifications . . . . .	24

## Revision History

Revision	Date	Author(s)	Description
1.0	27 Jan 2014	RND	First Version Editing
1.1	10 Aug 2014	MRK	Applications Revision
1.2	29 May 2015	RND	Features Revision
1.3	19 Nov 2015	RND	Specs Revision
1.4	25 Jul 2016	RND	Specs Revision
2.0	08 Jan 2017	BRND	Revised Format
2.1	17 Oct 2017	BRND	Branding Revisions
2.2	05 Feb 2018	MRK	Marketing Revisions
2.3	11 Oct 2018	RND	Specs Revisions
3.0	27 Dec 2019	BRND	Specs Revisions
3.0	28 Mar 2019	BRND	Features Revisions
3.1	3 Jun 2022	RND	Namur Section Added

1

1

- **Copyright:** All content on this document, such as text, graphics, logos and images is the property of Sapcon Instruments Pvt. Ltd. The selection, arrangement and presentation of all materials on this document and the overall design of this document is the exclusive property of Sapcon Instruments Pvt. Ltd.
- The images shown in this manual may differ from the actual instrument / housing in terms of dimensions, color and design. Please refer to GA drawings for dimensional details.
- Values (of performance) described in this manual were obtained under ideal testing conditions. Hence, they may differ under industrial environment and settings.

### General Instructions

- Instrument shouldn't block the material filling inlet.
- Secure the cover of housing tightly. Tighten the cable glands. For side mounting, the cable glands should point downwards.
- For side mounting, provide a baffle to prevent the material from falling on the probe.
- When handling forks, do not lift them using their tines. While using them with solids, ensure that material size is less than 10mm.
- Deforming the shape of the tines may interfere with the fork's operating frequency.
- Make all electrical connections as instructed in the manual. Don't power on the device before verifying the connections.

## 1 Introduction

Coat-Endure is a microcontroller based compact coat immune admittance level limit switch. It is a compact level switch which is suitable for sticky solids, pastes and slurries. The device is specially suited for compact silos and packaging machines where material has a tendency to stick on the probe.



Figure 1: Coat-Endure

## 2 Operating Principle

Coat-Endure is an improvement over traditional principle of admittance. The ring type probe has an alternating active and an inactive region, which collectively help the controller to calculate the extent of coating on the probe. In effect, the device is able to identify the differential coating between the sense and the shield by measuring their individual capacitances. As the coating immunity is controlled by the on-board microcontroller, the extent of coating immunity can be set easily.




Figure 2: Description of Parts

## 3 Features

- Universal power supply of 18 - 55 V DC and 90 - 265 V AC on the same terminal.
- Compact and customizable probe size.

- Passive shielding compensation with adjustable coating immunity.
- Output options: Relay, PNP and Analog.
- High temperature probe suitable for applications up to 250°C.
- Self-diagnosis for probe and electronics.
- Popular with a wide range of materials: low-to-high dielectric conductive materials.

## 4 Applications

- Food & Beverages
- Foundry
- Material Handling
- Poultry
- Packaging Industry
- Chemicals
- Pharmaceuticals
- Dairy



## 5 Electrical Specifications

Please refer to Table 8 for Electrical Specifications.

PARAMETER	VALUE
Input Power Supply	18 - 55V DC and 90 - 265V AC at 50Hz on same terminal
Available Output Options	Relay SPDT , PNP - Single Point Switching
Power Consumption	1.5W at 24 V
Switching Indication	Bi-color LED: Red - Alarm Green - Normal
Fail-safe	Field Selectable <ul style="list-style-type: none"> <li>• Open - Fail-safe High (For High Level)</li> <li>• Close - Fail-safe Low (For Low Level)</li> </ul>
Time Delay Setting	1 - 25 seconds (For both, Covered and Uncovered Delays)
Relay Rating	6 Amps at 230V AC

Table 1: Electrical Specifications

## 6 Mechanical Specifications

Please refer to Table 9 for Mechanical Specifications.

PARAMETER	VALUE
Housing	<ul style="list-style-type: none"> <li>• SCUTE: Pressure die-cast aluminium weatherproof (Rating IP-68)</li> <li>• FP2C: Cast aluminium, weatherproof &amp; flameproof, powder coated, suitable for Gas Groups IIA, IIB &amp; IIC as per IS-2148</li> </ul>
Electrical Connector	2 x 1/2" BSP/NPT , PG 13.5
Operating Temperature	0°C to 60°C (Electronics)
Process Temperature	Up to 250°C
Operating Pressure	Up to 10 bar
Mounting	<ul style="list-style-type: none"> <li>• Screwed: 1/2", 1", 1 1/2", 3/4" BSP / NPT</li> <li>• Flanged: As per user specification</li> </ul>
Probe Length	65 mm and (85 mm to 1500 mm)
Insulation	Part PTFE / Full PTFE

Table 2: Mechanical Specifications

## 7 Application Specifications

Please refer to Table 3 for Application Specifications.

PARAMETER	VALUE
Response Time	1 second
Sensitivity	Refer Table No. 12

Table 3: Application Specifications

## 8 Installation Guidelines

While installing the instrument, please take care of the following points:

1. The instrument should be installed in horizontal or vertical position only.




Figure 3: Proper Mounting Arrangement

2. Observe that when installed directly under the material inlet source, a canopy called baffle of appropriate strength and size should be welded right above the instrument as shown.




Figure 4: Coat-Endure with Baffle

3. To prevent the ingress of moisture and water seepage in side mounting position, the cable entries should always point downwards.




Figure 5: Cable Gland Arrangement

4. Secure the cover of housing tightly. Tighten the cable glands.


5. Make all electrical connections as instructed in the manual. Don't power on the device before verifying the connections.
6. Weatherproofness of enclosure is guaranteed only if the cover is in place glands adequately tightened. Damage due to accidental entry of water can be avoided if the instrument is installed in a rain shade.
7. If the ambient temperature is high, the instrument should not be installed to receive direct sunlight. In case such a position of shade is not available, a heat shield should be fitted above the instrument especially if the operating temperature lies between 60°C and 80°C.

## 9 Electrical Connections

Electrical connections for the instrument will change with the models. Please refer to figure 6 and the precautions mentioned below before connecting the device.

### Precautions for connecting Coat-Endure :

- **Power Supply Rating**  
Make sure the power supplied to the instrument is within the specified range mentioned in Table 8.
- **Connect Earth**  
When supplying AC power, please make sure that the grounding screw on the housing and the earth terminal are all connected to the plant's earth.
- **Power Supply Fluctuations & Noise**  
External noise or fluctuating power supplies could affect performance and shorten the life of the instrument. Use external line suppressors and fuse wires to contain the risk of damage to the circuit.



(a) Electronics option SPDT Relay and PNP Output(SPN)

Figure 6: Electrical Connections

## 10 Calibration

The DIP switches for calibration can be accessed by opening the top aluminium cover. Calibration process depends on the conductivity of the application material.

### 10.1 Calibration for Non-conductive Material

**Note:** Calibration in air is specific to the tank, if the tank changes, the instrument needs to be calibrated again.

This calibration is also known as **Air Calibration** and **Calibration without material**. It should be done without the application material (i.e only air, no material). Once calibrated in the empty tank, the device can be used with a wide range of materials. Calibrating the instrument outside the tank can cause malfunctions.




Figure 7: Calibration for Non-conductive Material

Follow the procedure given below to calibration the sensor:

- Install Coat-Endure in an empty tank.
- Unscrew the cover and ensure that all DIP switches are in the OPEN position as shown in Figure 45. Make sure that the status LED is not blinking for error.




Figure 8: DIP Switch

- To start the calibration process, set the CALIBRATE switch to CLOSE (Opposite of OPEN in a DIP switch) position as shown in Figure 46.




Figure 9: Calibration Switch Position




Figure 10: Setting Calibration

- Press and hold ENTER key. The STATUS LED for RELAY 1 will glow in RED color.
- Release the ENTER key and set the CALIBRATE switch back to OPEN position.




Figure 11: Saving Calibration

- Low calibration is done.

### 10.2 Calibration for Conductive Material

For applications using conductive materials (water, acid based pastes etc.), Coat-Endure needs to be calibrated with the application material. This will make the instrument specific to the application material i.e. if the application material is changed; calibration should be repeated.




Figure 12: Calibration for Conductive Material

Follow the procedure given below to calibration the sensor:

- Fill the tank with the application material such that the Coat-Endure's probe is completely covered with the material.
- Unscrew the cover and make sure that all DIP switches are in the OPEN position as shown in Figure 45. Ensure that the STATUS LED is not blinking for error.
- To start with the calibration, set the HI CALIBRATE switch to CLOSE (Opposite of OPEN for DIP switch) position as shown in Figure 50 and wait until Green LED becomes stable.




Figure 13: High Calibration Switch Position

- Press and hold ENTER key, the STATUS LED for RELAY 1 will glow in RED color as shown in Figure 51.




Figure 14: Setting Calibration

- Release the ENTER key and set the HI CALIBRATE switch back to OPEN position as shown in Figure 52.




Figure 15: Saving Calibration

- High Calibration is complete.

## 11 Cover Delay

**Note:** Set the value of Cover Delay between 1-25 secs.

When the application material covers the probe, the changeover of the output can be delayed by a pre-determined time. This time is called Cover Delay. For a different value of cover delay, the number of blinks can be adjusted as per requirement. Follow the procedure given below for setting cover delay:

- Ensure that all DIP switches are in OPEN position as shown in Figure 16. Make sure that STATUS LED is not blinking for error.
- Set the COVER switch to CLOSE (Opposite of OPEN in a DIP switch) position as shown in Figure 17.
- Press ENTER. The STATUS LED for RELAY 1 starts blinking. Blink the STATUS LED according to value of cover delay.




Figure 16: DIP Switch




Figure 17: Cover Switch Position




Figure 18: Setting Cover Delay

- Cover delay is entered, but not saved. To save and test the cover delay, set the COVER switch back to OPEN position as shown in Figure 19.




Figure 19: Saving Cover Delay

- To test, dip Coat-Endure into the application material until the switching point is reached.
- The STATUS LED will start blinking RED if the switch point is reached. It will blink for the number of seconds for which the cover delay is set. 1 blink is equal to 1 second during switching.

## 12 Uncover Delay

**Note:** Set the value of Uncover Delay between 1-25 secs.

When the application material uncovers Coat-Endure's probe, the changeover of the output can be delayed by a pre-determined time. This time is called Uncover Delay. For a different value of uncover delay, the number of blinks can be adjusted as per requirement. Follow the below procedure for setting uncover delay:

1. Ensure that all DIP switches are in OPEN position as shown in Figure 16. Make sure that STATUS LED is not blinking for error.
2. Set the UNCOVER switch to CLOSE (Opposite of OPEN in a DIP switch) position as shown in Figure 20.




Figure 20: Uncover Switch Position

3. Press ENTER. The STATUS LED for RELAY 1 starts blinking. Blink the STATUS LED according to value of uncover delay.




Figure 21: Setting Uncover Delay

4. Uncover Delay is entered, but not saved. To save and test the uncover delay, set the UNCOVER switch back to OPEN position as shown in Figure 22.




Figure 22: Saving Uncover Delay

5. To test, dip Coat-Endure into the application material until the switching point is achieved.
6. The STATUS LED will start blinking GREEN if the switch point is achieved. It will blink for the number of seconds for which the Uncover Delay is set.

## 13 Sensitivity

**Note:** Set the sensitivity value between 1-5.

Sensitivity of the level sensor may have to be adjusted depending on the dielectric constant of the application media. Coat-Endure has a LED bar display which helps in visualizing the desired sensitivity level. The device ships with a default sensitivity level of 3.

**Traverse the following steps to set the sensitivity of Coat-Endure:**

1. Set the UNCOVER and CALIBRATE switch to CLOSE position.




Figure 23: Sensitivity Bar Display

2. The Sensitivity Bar Display will indicate the current sensitivity value. As can be seen in the Figure 23, the value been shown here is 3.
3. To modify the set value, Press ENTER and HOLD the key, RED Status LED for RELAY 1 will start blinking. Count the number of times the LED blinks and release the ENTER key after the required value. e.g. For setting the sensitivity to 4, count up to four blinks and release the ENTER key.




Figure 24: Setting Sensitivity

4. To save the sensitivity value, set the UNCOVER and CALIBRATE switches back to OPEN position.




Figure 25: Setting Sensitivity

5. Check operation of Coat-Endure by filling in and draining out the material.
6. If the instrument does not switch when covered with the material, try again with a higher value of sensitivity.

7. If the instrument does not switch back to the uncovered state, try with a lower sensitivity value.

Select the sensitivity value with the help of Table 12.

SENSITIVITY	DIELECTRIC CONSTANT
1	> 30
2	20-30
3	5-20
4	2-5
5	> 1.5 & < 2

Table 4: Sensitivity

## 14 Failsafe

In a condition of device failure, known errors and input power failure the outputs of the device resemble the ALARM condition. This is meant to prevent overflow or dry run conditions in case of failures.

**Prevent Overflow - High Level Switch:** Failsafe High (default) is set by moving the FS 1 and FS 2 switch for RELAY 1 and 2 to OPEN position.

1. When not in contact with the material, LED turns GREEN.
2. When in contact with the material, LED turns RED.




Figure 26: Failsafe High

**Prevent Dry run - Low Level Switch:**

**Note:** LO in top cover indicates failsafe low.

Failsafe Low is set by moving the FS 1 and FS 2 switch for RELAY 1 and 2 switch to CLOSE position.

1. When in contact with the material, LED turns GREEN.
2. When not in contact with the material, LED turns RED.

## 15 Display Indications

As seen in Fig.28, Coat-Endure has STATUS LEDs and a 6-point LED bar display.

### 15.1 STATUS LED

Two separate STATUS LED sections indicate switching status for RELAY 1 and RELAY 2.




Figure 27: Failsafe Low




Figure 28: LED Indication on Top Cover

- **RED** LED: Alarm Condition
- **GREEN** LED: Normal Condition

Continuous blinking of Red or Green LED could indicate an error, refer to Error Indication

### 15.2 LED Bar Display

A numeric LED Bar displays helps to visualize switching point and sensitivity values.

**Use of LED Bar Display:** The bar display can be used for two purpose:

- Sensitivity: Refer to section Sensitivity for more details.
- Display Mode: The display mode shows the material distance from the instrument's probe. The movement of LEDs in upward direction depicts the movement of application media towards Coat-Endure's Probe and vice-versa, as shown in Figure 29.




Figure 29: Demonstration of LED Bar Display

## 16 Factory Reset

Follow the steps given below to reset the time delays and sensitivity value to default values. Factory Rest does not reset any calibration values:

1. Set the CALIBRATE, COVER and UNCOVER switches to CLOSE position.




Figure 30: Switch Position




Figure 33: Single Point Switching without Material

2. Press and hold the ENTER key until the STATUS LED blinks.




Figure 31: Setting Default Value

3. Set the CALIBRATE, COVER and UNCOVER switches back to OPEN position.




Figure 32: Saving Default Value

4. This will set the time delay to 0 and the sensitivity level to 3.

## 17 Output Options

Depending on the selection mode for output, the two relay outputs can also operate independently for two different switch points. Refer to Order Code

- All keys should be in the OPEN position.
- To see the output mode, press and hold ENTER key.
- If the only the first LED lights up, Coat-Endure is operating in the single point switching mode.

## 18 For AS-Interface Module

### 18.1 AS-Interface Topology

AS-Interface by design is a loop-powered digital bus. The 2-wire unshielded lines carry power as well as data on them. The single cabling system connects I/O devices with




Figure 34: AS-Interface

automation systems as shown in Figure 41. ASi-3 is based on a master-slave system where single master can transfer input and output data with up to 62 slaves.

## 18.2 Electrical Specifications

Please refer to Table 5 for Electrical Specifications.

PARAMETER	VALUE
Input Power Supply	24-30V DC
Electrical Connector	PG-13.5, 1/2" BSP DC Glands, 1/2" NPT DC Glands
Current Consumption	60mA @24V DC
Fail-safe Settings	User selectable (Field selectable through toggle switch) <ul style="list-style-type: none"> <li>• Open: Fail-safe High</li> <li>• Close: Fail-safe Low</li> </ul>

Table 5: Electrical Specifications

## 18.3 AS-i Configuration

Please refer to Table 6 for AS-Interface Configuration.

PARAMETER	VALUE
AS-i Version	3
Max. Slaves	62 Slave
Max. Cable Length	100m
Communication Method	Master/Slave with cyclic polling
Communication Speed	167 kbits/sec
Max. Data Size	8 bits

Table 6: AS-i Configuration

## 18.4 Electrical Connections



Please refer to the Figure 35 for electrical connections of AS-Interface Module.




Figure 35: Electrical Connection




Figure 36: Connection of Coat-Endure via AS-Interface

### 18.5 Setting Up AS-Interface

**Note:** ASi-4 and ASi-5 are later versions of the AS-i protocol. However, ASi-3 version is the most prevalent. ASi-4 & ASi-5 are backwards compatible with ASi-3.

AS-Interface can set up easily using a PLC with AS-Interface bus input. Follow these steps for setting up the AS-Interface bus with Coat-Endure:

- **Set Unique Bus ID:** Assign and set a unique bus identification for the slave device. This can be done by using an AS-I master device. Each device should have a unique bus identification. For setting the ID, there needs to be single device connected to the AS-Interface, other slaves need to be disconnected from the bus.
- **Check Configuration:** Use the failsafe switch to toggle the output and observe the change in the D0 bit for the assigned address. The output change can be observed via a PLC or a SCADA system connected to the PLC.




Figure 37: Output of AS-Interface

### 18.6 Installation

Proceed to Section [Installation Guidelines](#) for installing the product in an application tank and then refer to given Figure 35 for connecting Coat-Endure AS-i.

### 19 Error Indication

On error, the status LED starts blinking RED and GREEN alternately at a faster rate. Normal LED blinks are always at the rate of 1 blink per second, in either RED or GREEN color. In some cases, a GREEN or a RED blinking could indicate an error. Refer to Table 7 for a list of errors and their indication.

INDICATION	DESCRIPTION	TROUBLESHOOTING
RED-GREEN Blinking	Calibration Error	Recalibrate the instrument, make sure that the probe is calibrated in an empty metal-body tank.
RED Blinking	Probe Short-Circuit	Moisture deposition in the probe connector. Clean the connector and use the instrument.
GREEN Blinking	Probe Open	Remove the electronic insert from the housing and check the cable connections of the probe.
3 Times GREEN Blinking and 1 Red Blink	Illegal Key Combination	Switch all DIP switches to open position. Use only legal combination of keys.
3 Times RED Blinking and 1 GREEN Blink	Circuit Error	Contact the Customer Support department at Sapcon.

Table 7: Error Indication



## 20 For Namur Module

### 20.1 Electrical Specifications

Please refer to Table 8 for Electrical Specifications.

PARAMETER	VALUE
Input Power Supply	NMR: $8.5 \pm 0.2$ V DC. Namur type current output (I ON $\geq$ 2.1 mA, I OFF $\leq$ 1.2 mA) Namur compliance can be attained with a Namur certified isolator.
Ambient Temperature	-20°C to 60°C (Electronics)
Switching Indication	Red - Alarm & Green - Normal
Fail-safe	Field Selectable: Open - Fail-safe High (For High Level) Close - Fail-safe Low (For Low Level)

Table 8: Electrical Specifications

### 20.2 Mechanical Specifications

Please refer to Table 9 for Mechanical Specifications.

PARAMETER	VALUE
Housing	<ul style="list-style-type: none"> <li>• SCUTE: Pressure die-cast aluminium weatherproof (Rating IP-68)</li> <li>• FP2C: Cast aluminium, weatherproof &amp; flameproof, powder coated, suitable for Gas Groups IIA, IIB &amp; IIC as per IS-2148 (Rating IP-66)</li> </ul>
Cable Gland	2 x 1/2" BSP/NPT , PG 13.5
Mounting	<ul style="list-style-type: none"> <li>• Screwed: 1/2", 1", 1 1/2", 3/4" BSP / NPT</li> <li>• Flanged: As per user specification</li> </ul>
Probe Length	65 mm and (85 mm to 1500 mm)
Insulation	Part PTFE / Full PTFE

Table 9: Mechanical Specifications

## 21 Namur Isolation Barrier Specs

The 'NMR' electronics of the Coat-Endure requires the following specifications to be functional:

Parameter	Value
Functional Operating Voltage	$8.5 \pm 0.2$ V DC
Internal Source Resistance	1K $\Omega$
Absolute Maximum Voltage	UI & UO = 13 V
Current Consumption	II & IO = 16 mA
Power Consumption	PI & PO = 65 mW
Input Capacitance	0 $\mu$ F
Input Inductance	LI = 22 $\mu$ H
Certification	Ex ia IIC T6 Ga (-20°C $\leq$ Tamb $\leq$ 60°C)

Table 10: Namur Isolation Barrier Specifications

## 22 Installation Guidelines

The Coat-Endure can be installed in the vessel in almost any position. While installing, please take care of the following points:

- Ensure that atleast 10 mm for the "Grounding" electrode on the Coat-Endure probe should be completely inside the application tank. i.e. No part of sense or shield electrode should be inside the nozzle.




Figure 38: Grounding Length in an Application Tank

- Before Installing the device, ensure that the calibration process has been already carried out in safe area (Zone 2) then install the instrument in hazardous area as shown in Figure 39.




Figure 39: Calibration at safe zone

- For remote calibration, install the instrument in an application tank and then perform the calibration process in hazardous area (Zone 0).
- The instrument shouldn't block the material filling inlet.
- Secure the cover of housing tightly. Tighten the cable glands.
- For side-mounting, provide a baffle to prevent the material from falling on the probe. Please refer to Figure 40.
- To prevent the ingress of moisture and water seepage in side mounting position, the cable entries should always point downwards as shown in Figure 41.
- Make all electrical connections as instructed in the manual. Don't power on the device before verifying connections.




Figure 40: Coat-Endure with Baffle




Figure 41: Cable Gland Arrangement

- Weatherproofness of enclosure is guaranteed only if the cover is in place glands adequately tightened. Damage due to accidental entry of water can be avoided if the instrument is installed in a rain shade.
- If the ambient temperature is high, the instrument should not be installed to receive direct sunlight. In case such a position of shade is not available, a heat shield should be fitted above the instrument especially if the operating temperature is 60 °C.
- While screwing the Coat-Endure, the hexagonal mounting bush should be turned and not the housing.

### 22.1 Electrical Connections

Please refer to the Figure 42 for electrical connections while connecting the Elixir Namur in an application tank.




Figure 42: Electrical Connection during installation

### 22.2 Calibration

**Note:** Calibrator device must be used to power the instrument only when the level instrument is in a Safe Zone (Zone 2).

Calibration for the level sensor has to be carried out at the installation site. Calibration cannot be skipped and is essential for level sensor's operation. Calibration of Coat-Endure

can be performed with the help of two different methods which are as follows:

- Normal Calibration
- Remote Calibration

## 22.3 Normal Calibration

**Note:** Perform the Normal Calibration of the level instrument only in a Safe Zone (Zone 2).

### 22.3.1 Calibration for Non-conductive Material

This calibration is also known as **Air Calibration** and **Calibration without material**. It should be done without the application material (i.e only air, no material).

**It is recommended to first calibrate the Coat-Endure in a more convenient setup in Safe Zone(Zone 2) before installing it in the application tank.**

To carry out calibration process, please follow the steps mentioned below:

- Prepare a Metallic Test Tank as shown in the following Figure 43. The distance from test tank side walls should be of the same order as with distance with the actual tank.




Figure 43: Metallic Test Tank

- Refer to given Figure 42 for Electrical Connections to power up and connect the device.
- Dip the Coat-Endure into test tank as shown in Figure 44.




Figure 44: Calibration without Material

- Unscrew the cover and ensure that all DIP switches are in the OPEN position as shown in Figure 45. Make sure that the status LED is not blinking for error.



Figure 45: DIP Switch

- To start the calibration process, set the CALIBRATE switch to CLOSE (Opposite of OPEN in a DIP switch) position as shown in Figure 46.




Figure 46: Calibration Switch Position




Figure 47: Setting Calibration

- Press and hold ENTER key. The STATUS LED will glow in RED color.
- Release the ENTER key and set the CALIBRATE switch back to OPEN position.




Figure 48: Saving Calibration

- Air calibration is done.
- Proceed to Section [Installation Guidelines](#) for installing the product in an application tank.

### 22.3.2 Calibration for Conductive Material

For applications using conductive materials (water, acid based pastes etc.), Coat-Endure needs to be calibrated with the application material. This will make the instrument specific to the application material i.e. if the application material is changed; calibration should be repeated.

**It is recommended to first calibrate the Coat-Endure in a more convenient setup in Safe Zone(Zone 2) before installing it in the application tank.**

To carry out calibration process, please follow the steps mentioned below:

- Prepare a Metallic Test Tank as shown in the following Figure 43.
- Refer to given Figure 42 for Electrical Connections to power up and connect the device.
- Dip the Coat-Endure in test tank & fill the tank with the application material such that the Coat-Endure's probe is completely covered with the material.




Figure 49: Calibration for Conductive Material

- Unscrew the cover and make sure that all DIP switches are in the OPEN position as shown in Figure 45. Ensure that the STATUS LED is not blinking for error.
- To start with the calibration, set the CALIBRATE & COVER switch to CLOSE (Opposite of OPEN for DIP switch) position as shown in Figure 50.




Figure 50: High Calibration Switch Position

- Press and hold ENTER key, the STATUS LED will glow in RED color as shown in Figure 51.




Figure 51: Setting Calibration

- Release the ENTER key and wait for 25 - 30 seconds.
- Set the CALIBRATE and COVER switch back to OPEN position as shown in Figure 52.




Figure 52: Saving Calibration

- High Calibration is complete.
- Proceed to Section [Installation Guidelines](#) for installing the product in an application tank.

**Note:** Remote calibration is performed when test tank is not available in Safe Zone (Zone 2) and calibration needs to be performed in Hazardous Zone (Zone 0).

### 22.4.1 Calibration for Non-conductive Material

This calibration is also known as **Air Calibration** and **Calibration without material**. It should be done without the application material (i.e only air, no material).

**Note:** Power OFF the level instrument before starting the calibration process.

To carry out calibration process, please follow the steps mentioned below:

- Ensure that all DIP switches are in the OPEN position.




Figure 53: Remote Air Calibration Setup

- Set the CALIBRATE switch to CLOSE (Opposite of OPEN in a DIP switch) position as shown in Figure 46.
- Close the cover of housing properly before powering on the instrument.
- Power ON the instrument and wait for a minimum of 60 seconds.

60 Seconds




Figure 54: Power ON Condition

- Power OFF the instrument.
- Open the housing cover and set the CALIBRATE switch back to OPEN position as shown in Figure 48.
- Close the cover of housing properly.
- Power ON the instrument.
- Low calibration is completed.

## 22.4 Remote Calibration

## 22.4.2 Calibration for Conductive Material

For applications using conductive materials (water, acid based pastes etc.), Coat-Endure needs to be calibrated with the application material. This will make the instrument specific to the application material i.e. if the application material is changed; calibration should be repeated.

**Note:** Power OFF the level instrument before starting the calibration process.

To carry out calibration process, please follow the steps mentioned below:

- Ensure that all DIP switches are in the OPEN position.




Figure 55: Remote High Calibration Setup

- Set the CALIBRATE and COVER switch to CLOSE (Opposite of OPEN in a DIP switch) position as shown in Figure 50.
- Close the cover of housing properly before powering on the instrument.
- Power ON the instrument and wait for a minimum of 60 seconds.




Figure 56: High Calibration Power ON Condition

- Power OFF the instrument.
- Open the housing cover and set the CALIBRATE and COVER switch back to OPEN position as shown in Figure 52.
- Close the cover of housing properly.
- Power ON the instrument.
- High calibration is completed.

## 23 Output Current Configuration

**Note:** Perform the operation of Output Current Configuration of the level instrument only in a Safe Zone (Zone 2).

Namur isolation barriers as specified in the Table 11 tend to have variation in their "Functional Operating Voltage". Change to the "Functional Operating Voltage" may cause a change in power consumption for Coat-Endure Namur level sensor. The output current can be configured as per the procedure mentioned below:

If the output current of alarm condition exceeds or goes below the specified limit only then use Low Current Configuration or High Current Configuration as per the current value.

STATUS	OUTPUT CURRENT
Normal Condition	$\leq 1.2\text{mA}$
Alarm Condition	$\geq 2.1\text{mA}$ and $< 3\text{mA}$

Table 11: Operating Conditions of Output Current

### 23.1 Low Current Configuration

If the output current of alarm condition is exceed over **3mA** then the instrument does not operate properly which results instrument will not be able to switch. To resolve this condition, the value of output current should be adjusted by setting Low Current Configuration. To set this mode please follow the procedure given below:

- Set the COVER and UNCOVER switch to CLOSE position.




Figure 57: Switch Position Low Current Configuration

- Press and Hold the ENTER key, RED Status LED will start blinking.




Figure 58: Setting of Low Current Configuration

- Blink the RED LED 2 times and release the ENTER key.
- Low Current Configuration mode is set.




Figure 59: Saving of Low Current Configuration

## 23.2 High Current Configuration

If the output current of alarm condition goes below **2.1mA** then the instrument does not operate properly which results instrument will not be able to switch. To resolve this condition, the value of output current should be adjusted by setting High Current Configuration. **Indication of this mode is shown by constantly glowing GREEN LED of STATUS LED.** To set this mode please follow the procedure given below:

- Set the COVER and UNCOVER switch to CLOSE position as per Figure 57.
- Press and Hold the ENTER key, RED Status LED will start blinking as per Figure 58.
- Blink the RED LED only once and release the ENTER key as per Figure 59.
- High Current Configuration mode is set.

## 24 Sensitivity

**Note: Set the sensitivity value between 1-5.**

The instrument has 5-point sensitivity level to suit a wide range of application materials. Sensitivity value should be decided with respect to the dielectric constant and coating thickness of the application material. Refer to table 12 for selecting a suitable value. By default, the sensitivity is set to 3 to suit a wide range of materials. Traverse the following steps to set the sensitivity:

**Note: Set the Sensitivity of the level instrument only in a Safe Zone (Zone 2).**

1. Power OFF the instrument and unscrew the electronics insert from the enclosure using screw driver.
2. Kept the electronics in Safe Zone(Zone 2) and then set the Sensitivity.
3. Refer to given Figure 42 for Electrical Connections to power up and connect the device.
4. Select a sensitivity value for the product as per table 12.
5. Set the CALIBRATE and UNCOVER switch to CLOSE position.

### Hazardous Area (Zone 0)

Power OFF Condition




Figure 60: Sensitivity Setting

DIELECTRIC CONSTANT	COATING THICKNESS	SENSITIVITY VALUE
High	High	1 – 3
Low	High	3 – 5 (default)
High	Low	1 – 2
Low	Low	5

Table 12: Switching Sensitivity




Figure 61: Sensitivity Switch Position

6. To modify the set value, Press ENTER and HOLD the key, RED Status LED will start blinking. Count the number of times the LED blinks and release the ENTER key after the required value. e.g. For setting the sensitivity to 4, count up to four blinks and release the ENTER key.




Figure 62: Setting Sensitivity Position

7. To save the sensitivity value, set the CALIBRATE and UNCOVER switches back to OPEN position.
8. Check operation of Coat-Endure by filling in and draining out the material.
9. If the instrument does not switch when covered fully with the material, try again with a higher value of sensitivity.




Figure 63: Saving Sensitivity

- If the instrument switches when covered fully with the material, but does not switch back to normal state when uncovered, try again with a lower sensitivity value.

## 25 Failsafe

In a condition of device failure, known errors and input power failure the outputs of the device resemble the ALARM condition. This is meant to prevent overflow or dry run conditions in case of failures.

**Note:** Perform the Failsafe operation in Power OFF condition in hazardous area (Zone 0).

**Prevent Overflow - High Level Switch:** Failsafe High (default) is set by moving the FAILSAFE switch to OPEN position.

- When not in contact with the material, LED turns GREEN.
- When in contact with the material, LED turns RED.




Figure 64: Failsafe High

**Prevent Dry run - Low Level Switch:** Failsafe Low is set by moving the FAILSAFE switch to CLOSE position.

- When in contact with the material, LED turns GREEN.
- When not in contact with the material, LED turns RED.




Figure 65: Failsafe Low

## 26 Factory Reset

Follow the steps given below to reset the time delays and sensitivity value to default values. Factory Reset does not reset any calibration values.

- Set the CALIBRATE, COVER and UNCOVER switches to CLOSE position.




Figure 66: Switch Position

- Press and hold the ENTER key until the STATUS LED blinks.




Figure 67: Setting Default Value

- Set the CALIBRATE, COVER and UNCOVER switches back to OPEN position.




Figure 68: Saving Default Value

- This will set the time delay to 0 and the sensitivity level to 3.

## 27 Certification

CERTIFICATION	ITEM SELECTION
IS/IEC 60529: 2001 (IP68)	SCUTE
IS/IEC 60529: 2001 (IP66)	FP2C
IS/IEC 60079-1:2014 (Ex 'd')	FP2C
Ex ia IIC T6 Ga	NMR-DC6

Table 13: Certifications

## 28 Maintenance

The electronics of Coat-Endure needs no maintenance. When cleaning and checking the vessel, free the Coat-Endure from deposits. If the material has tendency to form a hard sticky deposit, the instrument must be checked more often. Make sure that the cable ducts and the lid are tightly sealed so that no moisture seeps into the instrument.

### 28.1 Customer Support

Thank you for going through the instructions given in this manual. To further ease the process of installation and use, we have developed special demo videos which are hosted on YouTube.

Sapcon's YouTube channel, SAPCON INSTRUMENTS, lists all these videos: <https://goo.gl/dnxfcz>

Should you require further information regarding installation, use or working of the instrument, please don't hesitate to contact us. Kindly provide the following information at the time of contacting:

- Instrument Model and Serial Number
- Purchase Order Number and Date of Purchase
- Description of the query
- Your contact details

In an attempt to serve you better, we are open seven days a week (9:30am to 7:30pm). We are available at:

- [www.sapconinstruments.com](http://www.sapconinstruments.com)
- [sales@sapcon.in](mailto:sales@sapcon.in)
- +91-731-4757575



## 29 Namur Selection Order Code

### Product

**CE : Coat Endure - Compact Admittance Level Limit Switch (Use in Sticky Solids, Pastes and Slurries)**

#### Type

I : Integral (sensor in same unit)

#### Housing

SCUTE : Pressure Die Cast Aluminium weather proof (Rating IP68) SCUTE

FP2C : Cast Aluminium weather & flame proof powder coated paint suitable for gas group IIC (Rating IP-66)

#### Probe Housing Cable Entry

PCPG13 : PG 13.5, Polyamide

PCB5D : 1/2" BSP, DC Gland, Brass

PCN5D : 1/2" NPT, DC Gland, Brass

#### Output

NMR : Namur type current output at  $8.5 \pm 0.2$  V DC ( $I_{ON} \geq 2.1$  mA and  $I_{OFF} \leq 1.2$  mA)

#### Power Supply

DC6 :  $8.5 \pm 0.2$  V DC supplied by NAMUR certified isolator should contain 1K $\Omega$  Internal Resistor

#### Insulation Type

P : Part PTFE

F : Full PTFE

#### Mounting

MB5S4 : Screwed Thread, BSP 1/2", SS 304

MB5S6 : Screwed Thread, BSP 1/2", SS 316

MN5S4 : Screwed Thread, NPT 1/2", SS 304

MN5S6 : Screwed Thread, NPT 1/2", SS 316

MB75S4 : Screwed Thread, BSP 3/4", SS 304

MB75S6 : Screwed Thread, BSP 3/4", SS 316

MN75S4 : Screwed Thread, NPT 3/4", SS 304

MN75S6 : Screwed Thread, NPT 3/4", SS 316

MB10S4 : Screwed Thread, BSP 1", SS 304

MB10S6 : Screwed Thread, BSP 1", SS 316

MN10S4 : Screwed Thread, NPT 1", SS 304

MN10S6 : Screwed Thread, NPT 1", SS 316

MB15S4 : Screwed Thread, BSP 1-1/2", SS 304

MB15S6 : Screwed Thread, BSP 1-1/2", SS 316

MN15S4 : Screwed Thread, NPT 1-1/2", SS 304

MN15S6 : Screwed Thread, NPT 1-1/2", SS 316

F10S4 : 1" ASA Flange, 10mm thickness, SS 304

F10S6 : 1" ASA Flange, 10mm thickness, SS 316

F15S4 : 1-1/2" ASA Flange, 10mm thickness, SS 304

F15S6 : 1-1/2" ASA Flange, 10mm thickness, SS 316

F20S4 : 2" ASA Flange, 10mm thickness, SS 304

F20S6 : 2" ASA Flange, 10mm thickness, SS 316

F25S4 : 2-1/2" ASA Flange, 10mm thickness, SS 304

F25S6 : 2-1/2" ASA Flange, 10mm thickness, SS 316

<b>Mounting</b>
FA10S4 : 1" ANSI Flange, SS 304
FA10S6 : 1" ANSI Flange, SS 316
FA15S4 : 1-1/2" ANSI Flange, SS 304
FA15S6 : 1-1/2" ANSI Flange, SS 316
FA20S4 : 2" ANSI Flange, SS 304
FA20S6 : 2" ANSI Flange, SS 316
FA25S4 : 2-1/2" ANSI Flange, SS 304
FA25S6 : 2-1/2" ANSI Flange, SS 316
<b>Sense</b>
S20S4 : 20mm Length, SS 304 (Only for Probe Length $\leq$ 150mm)
S20S6 : 20mm Length, SS 316 (Only for Probe Length $\leq$ 150mm)
S40S4 : 40mm Length, SS 304 (Only for Probe Length $\geq$ 151mm)
S40S6 : 40mm Length, SS 316 (Only for Probe Length $\geq$ 151mm)
<b>Shield (Depends on "Sense")</b>
SH11S4 : 11mm Length, SS 304 (Only with "S20S4")
SH11S6 : 11mm Length, SS 316 (Only with "S20S6")
SH20S4 : 20mm Length, SS 304 (Only with "S40S4")
SH20S6 : 20mm Length, SS 316 (Only with "S40S6")
<b>Grounding Length (Depends on Probe Length <math>\geq</math> 85mm or 0.85H)</b>
GS4 : SS 304
GS6 : SS 316
<b>Operating Temperature</b>
10T : Upto 100°C
20T : Upto 200°C
<b>Standoff Material (Only with "25T")</b>
STGI : GI (Galvanized Iron)
STS4 : SS 304
STS6 : SS 316
<b>Probe Length</b>
0.65H : 65mm
0.85H1.5H : 85mm to 150mm
1.5H15H : 151mm to 1500mm

Example - **CE-I-SCUTE-PCPG13-NMR-DC6-P-MB10S4-S20S4-SH11S4-10T-0.65H**

## 30 Product Selection Order Code

### Product

**CE : Coat Endure - Compact Admittance Level Limit Switch (Use in Sticky Solids, Pastes and Slurries)**

#### Type

I : Integral (sensor in same unit)

#### Indication (Optional)

WL : External LED Indication infrared output

#### Housing

SCUTE : Pressure Die Cast Aluminium weather proof (Rating IP68) SCUTE

FP2C : Cast Aluminium weather & flame proof powder coated paint suitable for gas group IIC

#### Probe Housing Cable Entry

PCPG13 : PG 13.5, Polyamide

PCB5D : 1/2" BSP, DC Gland, Brass

PCN5D : 1/2" NPT, DC Gland, Brass

#### Output

D : 2NO, 2NC DPDT Relay Output (rated at 6 A, 230 V AC for non-inductive load)

SPN : SPDT Relay Output 1NO, 1NC (Relay rated at 6 A, 230 V AC for non-inductive load) and PNP Output (only for supply voltage 18V to 30V DC)

#### Power Supply (Depend on "Housing")

U : Universal (18 to 55V DC) and (90 to 265V at 50Hz AC) on same terminals

#### Insulation Type

P : Part PTFE

F : Full PTFE

#### Mounting

MB5S4 : Screwed Thread, BSP 1/2", SS 304

MB5S6 : Screwed Thread, BSP 1/2", SS 316

MN5S4 : Screwed Thread, NPT 1/2", SS 304

MN5S6 : Screwed Thread, NPT 1/2", SS 316

MB75S4 : Screwed Thread, BSP 3/4", SS 304

MB75S6 : Screwed Thread, BSP 3/4", SS 316

MN75S4 : Screwed Thread, NPT 3/4", SS 304

MN75S6 : Screwed Thread, NPT 3/4", SS 316

MB10S4 : Screwed Thread, BSP 1", SS 304

MB10S6 : Screwed Thread, BSP 1", SS 316

MN10S4 : Screwed Thread, NPT 1", SS 304

MN10S6 : Screwed Thread, NPT 1", SS 316

MB15S4 : Screwed Thread, BSP 1-1/2", SS 304

MB15S6 : Screwed Thread, BSP 1-1/2", SS 316

MN15S4 : Screwed Thread, NPT 1-1/2", SS 304

MN15S6 : Screwed Thread, NPT 1-1/2", SS 316

F10S4 : 1" ASA Flange, 10mm thickness, SS 304

F10S6 : 1" ASA Flange, 10mm thickness, SS 316

F15S4 : 1-1/2" ASA Flange, 10mm thickness, SS 304

F15S6 : 1-1/2" ASA Flange, 10mm thickness, SS 316

<b>Mounting</b>	
	F20S4 : 2" ASA Flange, 10mm thickness, SS 304
	F20S6 : 2" ASA Flange, 10mm thickness, SS 316
	F25S4 : 2-1/2" ASA Flange, 10mm thickness, SS 304
	F25S6 : 2-1/2" ASA Flange, 10mm thickness, SS 316
	FA10S4 : 1" ANSI Flange, SS 304
	FA10S6 : 1" ANSI Flange, SS 316
	FA15S4 : 1-1/2" ANSI Flange, SS 304
	FA15S6 : 1-1/2" ANSI Flange, SS 316
	FA20S4 : 2" ANSI Flange, SS 304
	FA20S6 : 2" ANSI Flange, SS 316
	FA25S4 : 2-1/2" ANSI Flange, SS 304
	FA25S6 : 2-1/2" ANSI Flange, SS 316
<b>Sense</b>	
	S20S4 : 20mm Length, SS 304 (Only for Probe Length $\leq$ 150mm)
	S20S6 : 20mm Length, SS 316 (Only for Probe Length $\leq$ 150mm)
	S40S4 : 40mm Length, SS 304 (Only for Probe Length $\geq$ 151mm)
	S40S6 : 40mm Length, SS 316 (Only for Probe Length $\geq$ 151mm)
<b>Shield (Depends on "Sense")</b>	
	SH11S4 : 11mm Length, SS 304 (Only with "S20S4")
	SH11S6 : 11mm Length, SS 316 (Only with "S20S6")
	SH20S4 : 20mm Length, SS 304 (Only with "S40S4")
	SH20S6 : 20mm Length, SS 316 (Only with "S40S6")
<b>Grounding Length (Depends on Probe Length <math>\geq</math> 85mm or 0.85H)</b>	
	GS4 : SS 304
	GS6 : SS 316
<b>Operating Temperature</b>	
	10T : Upto 100°C
	25T : Upto 250°C
<b>Standoff Material (Only with "25T")</b>	
	STGI : GI (Galvanized Iron)
	STS4 : SS 304
	STS6 : SS 316
<b>Probe Length</b>	
	0.65H : 65mm
	0.85H1.5H : 85mm to 150mm
	1.5H15H : 151mm to 1500mm

Example - CE-I-SCUTE-PCPG13-D-U-P-MB10S4-S20S4-SH11S4-10T-0.65H

## 31 AS-Interface Order Code

### Product

**CE : Coat Endure - Compact Admittance Level Limit Switch (Use in Sticky Solids, Pastes and Slurries)**

#### Type

I : Integral (sensor in same unit)

#### Indication (Optional)

WL : External LED Indication infrared output

#### Housing

SCUTE : Pressure Die Cast Aluminium weather proof (Rating IP68) SCUTE

FP2C : Cast Aluminium weather & flame proof powder coated paint suitable for gas group IIC

#### Probe Housing Cable Entry

PCPG13 : PG 13.5, Polyamide

PCB5D : 1/2" BSP, DC Gland, Brass

PCN5D : 1/2" NPT, DC Gland, Brass

#### Output

ASi-3 : ASi-3, Actuator Sensor Interface, 4-bit bus

#### Insulation Type

P : Part PTFE

F : Full PTFE

#### Mounting

MB5S4 : Screwed Thread, BSP 1/2", SS 304

MB5S6 : Screwed Thread, BSP 1/2", SS 316

MN5S4 : Screwed Thread, NPT 1/2", SS 304

MN5S6 : Screwed Thread, NPT 1/2", SS 316

MB75S4 : Screwed Thread, BSP 3/4", SS 304

MB75S6 : Screwed Thread, BSP 3/4", SS 316

MN75S4 : Screwed Thread, NPT 3/4", SS 304

MN75S6 : Screwed Thread, NPT 3/4", SS 316

MB10S4 : Screwed Thread, BSP 1", SS 304

MB10S6 : Screwed Thread, BSP 1", SS 316

MN10S4 : Screwed Thread, NPT 1", SS 304

MN10S6 : Screwed Thread, NPT 1", SS 316

MB15S4 : Screwed Thread, BSP 1-1/2", SS 304

MB15S6 : Screwed Thread, BSP 1-1/2", SS 316

MN15S4 : Screwed Thread, NPT 1-1/2", SS 304

MN15S6 : Screwed Thread, NPT 1-1/2", SS 316

F10S4 : 1" ASA Flange, 10mm thickness, SS 304

F10S6 : 1" ASA Flange, 10mm thickness, SS 316

F15S4 : 1-1/2" ASA Flange, 10mm thickness, SS 304

F15S6 : 1-1/2" ASA Flange, 10mm thickness, SS 316

F20S4 : 2" ASA Flange, 10mm thickness, SS 304

F20S6 : 2" ASA Flange, 10mm thickness, SS 316

F25S4 : 2-1/2" ASA Flange, 10mm thickness, SS 304

F25S6 : 2-1/2" ASA Flange, 10mm thickness, SS 316

<b>Mounting</b>
FA10S4 : 1" ANSI Flange, SS 304
FA10S6 : 1" ANSI Flange, SS 316
FA15S4 : 1-1/2" ANSI Flange, SS 304
FA15S6 : 1-1/2" ANSI Flange, SS 316
FA20S4 : 2" ANSI Flange, SS 304
FA20S6 : 2" ANSI Flange, SS 316
FA25S4 : 2-1/2" ANSI Flange, SS 304
FA25S6 : 2-1/2" ANSI Flange, SS 316
<b>Sense</b>
S20S4 : 20mm Length, SS 304 (Only for Probe Length $\leq$ 150mm)
S20S6 : 20mm Length, SS 316 (Only for Probe Length $\leq$ 150mm)
S40S4 : 40mm Length, SS 304 (Only for Probe Length $\geq$ 151mm)
S40S6 : 40mm Length, SS 316 (Only for Probe Length $\geq$ 151mm)
<b>Shield (Depends on "Sense")</b>
SH11S4 : 11mm Length, SS 304 (Only with "S20S4")
SH11S6 : 11mm Length, SS 316 (Only with "S20S6")
SH20S4 : 20mm Length, SS 304 (Only with "S40S4")
SH20S6 : 20mm Length, SS 316 (Only with "S40S6")
<b>Grounding Length (Depends on Probe Length <math>\geq</math> 85mm or 0.85H)</b>
GS4 : SS 304
GS6 : SS 316
<b>Operating Temperature</b>
10T : Upto 100°C
25T : Upto 250°C
<b>Standoff Material (Only with "25T")</b>
STGI : GI (Galvanized Iron)
STS4 : SS 304
STS6 : SS 316
<b>Probe Length</b>
0.65H : 65mm
0.85H1.5H : 85mm to 150mm
1.5H15H : 151mm to 1500mm

Example - CE-I-SCUTE-PCPG13-ASi-3-P-MB10S4-S20S4-SH11S4-10T-0.65H